

Denon DN-F300 Firmware Installation instructions

Version 17.30

1. If you haven't already extract the update folder named 'FW_DNF3001730_20120605.zip'. After extracting the folder you will now see the two update files inside that folder. These are named 'DNF30C1700.bin' and 'DNF30026.bin'.
2. Drag and drop both of these .bin files to the root of a SD card or USB storage device.
3. With the power turned *Off* on the DN-F300 place the SD card or USB device into the machine and power *On* the DN-F300.
4. Once the DN-F300 is powered on you will be prompted on the display to start the update. If not please ensure that the proper media is selected on the DN-F300.
5. Once the DN-F300 completes the firmware update and reboots, remove your media and delete the update files.

Firmware Details V17.30

- Wav files have left and right reversed.

Previous Firmware Details

- Resolved sound passing issue when in Repeat and Single modes.
- Modified level hierarchy.
- Resolved maximum file size limitation of 340 MB.
- Resolved issue with Sony branded SD cards.
- Resolved unwanted 'popping' sounds in between tracks.
- Audio is not output during frame search.

How to check the firmware version of the DN-F300

1. With the power turned *On* press and hold the DISP / MENU button until the preset menu appears.
2. Turn the FOLDER / TRACK knob until FW Version is displayed and press the knob in.
3. The current version number will be displayed on the screen.
4. Press (do not hold) the DISP / MENU button to exit the preset menu.