

ENGLISH

FRANÇAIS

ESPAÑOL

DEUTSCH

ITALIANO

NEDERLANDS

SVENSKA

日本語

### 21 (Page / Page / Página / Seite / Pagina / Bladzijde / Sida / ページ)

Fader Start

Play, Play-Pause, Play w/K.Lock (With KeyLock), Play-Pause/KL (With KeyLock)

### 24 (Page / Page / Página / Seite / Pagina / Bladzijde / Sida / ページ)

Play

Play-Pause (default / valeur par défaut / predeterminado / Standard / predefinito / standaard / standard / 初期設定)

➡ Play w/K.Lock (With KeyLock)

➡ Play-Pause/KL (With KeyLock)

### 38 (Page / Page / Página / Seite / Pagina / Bladzijde / Sida / ページ)

"@0FDPU"+CR

Fader Start - PlayPause

➡ "@0FDPK"+CR

Fader Start - Play w/K.Lock (With KeyLock)

➡ "@0FDUK"+CR

Fader Start - Play-Pause/KL (With KeyLock)

"@0IT12"+CR

Index Tally Index2

### 40 (Page / Page / Página / Seite / Pagina / Bladzijde / Sida / ページ)

Fader Start

"@0?FD"+CR

Play

"@0FDPL"+CR

PlayPause

"@0FDPU"+CR

➡ Play w/K.Lock (With KeyLock)

"@0FDPK"+CR

➡ Play-Pause/KL (With KeyLock)

"@0FDUK"+CR