

Denon Professional

DN-F350 Firmware Update Instructions

1. With the DN-F350 powered off, on the rear of the unit switch from Normal to **UPDATE**.
2. Add the **DN-F350.bin** file to a FAT32 formatted USB drive.
3. Plug in the USB drive to the rear USB port on the DN-F350.
4. Power on the DN-F350. The display will show **UPDATE** and have an “**N**” for No or a “**Y**” for Yes. Use the encoder to change to **Y**. **Press in the Encoder knob** to begin the firmware update.
5. Once the firmware update is complete, the display will show **SUCCEED**. Power **off** the unit, switch the rear back to **NORMAL**. Remove the USB drive.
6. To check the firmware version, **long-press** the Encoder knob to enter the **Menu**. Use the encoder knob to scroll to **<System Version>**. Press the encoder knob in to view the firmware version now installed.

V1.12

Various bug fixes. Eliminates momentary audio playback during song change.