



DN-700C

Latest Firmware Version: A-2.35

Release Date: July 1, 2015

Update Process and Verification

Important: Before updating to the latest firmware, please make sure your DN-700C is using Firmware Version **A-2.14** or later. If it is not, please update to A-2.14 **before** updating to A-2.35: follow all of the steps below using the **DN700CFW.bin** file, and then repeat the same procedure using the **DN700CFWA.bin** file.

To update the firmware on your DN-700C:

1. Unzip the contents of the downloaded **.zip** file to your Desktop.
2. Transfer the **DN700CFWA.bin** file from that **.zip** file to the root directory of a USB storage device.
3. Make sure your DN-700C is securely connected to a power outlet and is powered off, and then insert the USB storage device into it.
4. Power on DN-700C.
5. DN-700C's display will show the new firmware version number. Confirm the version number is correct.
6. To continue with the update, turn the **Jog Wheel** on the front panel to select **OK**, and then press the **Jog Wheel**. *During the update process, do not power off DN-700C or disconnect it from the power outlet. Doing so can damage the unit.*

To cancel the operation instead, turn the **Jog Wheel** on the front panel to select **Cancel**, and then press the **Jog Wheel**.

7. Allow the update process to complete, which may take approximately 1 minute. The display may go dark during this time. After the update is completed, DN-700C will automatically restart. Remove your USB storage device, and delete the **.bin** files.

Your DN-700C now has the newest firmware.

To check the firmware version on your DN-700C:

1. With the DN-700C powered on and stopped, press the **Menu** key.
2. Select **06 Utility** and press the **Jog Wheel**.
3. Select **03 Firmware Version** and press the **Jog Wheel**. The installed firmware version will appear in the display.

Changes

Firmware Version A-2.35 (July 2015)

- Added auto-power down functionality for ErP.

Firmware Version A-2.33 (September 2014)

- Added ability to manually select whether or not the pitch value is recalled.
- Added ability to assign the button to change the pitch.
- Fixed an issue where the preset file occasionally did not load completely.

Firmware Version A-2.32 (May 2014)

- Added hotlist file (.ppl) function created by RC-F400S loading automatically.
- Added ability to forcibly eject disc by pressing **Shift** and **Eject** simultaneously when the **Shift** button mode is set to **Momentary**.
- Improved CD reading performance.
- Improved detection performance of USB device when starting up.
- Fixed an issue where continuous playback of DLNA contents can stop in a certain environment.
- Fixed an issue where TCP/IP packet response can be occasionally delayed.

Firmware Version A-2.30 (March 2014)

- Fixed the function of the **D&M RC Communication format** commands.
- Improved CD playback performance.
- Fixed an issue where a pop noise occasionally occurred when finishing media playback.
- Fixed the functionality of **Extended Communication Format (MIDI)**.

Firmware Version A-2.25 (January 2014)

- Added **Web Remote** customization function.
- Fixed an issue where transferring to **Utility** and **System** settings via Web Remote display in iOS device did not work.
- Improved CD reading performance.
- Fixed the function that stores Hotlist files by using RC-F400S.
- Fixed an issue where the RC-F400S display sometimes displays **Wait...** popup continuously after inserting USB media.

Firmware Version A-2.23 (November 2013)

- Added MIDI command to change playback media.
- Fixed MIDI command error.

- Fixed an issue where occasional pop noises occurred when changing FS or media.
- Fixed an issue where the unit can freeze after playing specified wave files.
- Fixed an issue where playback status changes to **Cue** after changing media from **CD** to **USB**.
- Fixed an issue where network media folders did not appear on Web Remote display when **Play Range** is set to **All**.
- Fixed an issue where the pitch button would sometimes not work.

Firmware Version A-2.13 (September 2013)

- Added **Enter** and **Back** buttons to Web Remote GUI.
- Added displayed message to Web Remote GUI when playback status is not **Stop** or **Cue** in the **Preset** or **System** setting display.
- Added displayed message to Web Remote GUI when the selected media is unavailable.
- Added displayed message to Web Remote GUI when the unit encounters an error.
- Added support for Mozilla Firefox browser.
- Changed display of track number in Web Remote GUI so the number flashes when using the **Next Track Reserve** function.
- Changed **Load** to **Load File** and **Enter** to **Enter Folder** in Web Remote GUI.
- Added pitch and volume reset buttons to Web Remote GUI.
- Added display of machine name to browser tag area.
- Changed UPnP icon design.
- Added ability to switch power control and machine detection (from the project manager) in the **Preset** menu.
- Added end monitor function.
- Added Japanese font.
- Fixed OLED contrast range.
- Fixed other minor issues.

Firmware Version A-1.10 (May 2013)

- Fixed an issue where the RC-F400S update function did not work.

Technical Support

For additional help, visit denonpro.com/support.