

## **DN-F400 Firmware v1.12 Update Instructions**

1. Power off the DN-F400.
2. Transfer DN-F400.bin file to the root of the SD card. Be sure no other update files are present on the card.
3. Insert SD card to the DN-F400.
4. Power on DN-F400.
5. When prompted "Update A-1.XX?", select Yes. To toggle selections, use the Track Select buttons and use the Play button for enter.
6. Leave power on during the updating process. If power is interrupted, the machine may require service.
7. Once the machine is completed with the update process and prompts "Update A-1.XX?" again, select No.
8. Power down the unit.
9. Remove card from the machine and delete the update file.
10. The update is now complete.