


# Denon Pro DN-500CB


## Firmware Update Instructions

This firmware update requires an RS-232 cable connecting the DN-500CB and the computer. It also requires the software included with this download.


1. Connect the RS-232 cable to the DN-500CB and the computer. Put the switch next to the RS-232 port to **UPDATE**.
2. Power on the DN-500CB.
3. Install and open the included firmware update software.
  - i. Choose the COM port from the PC. Then press Next.




ii. Press Next.




iii. Press Next.



iv. Follow the steps below:



v. The program will show the progression of the upgrade and when complete, will show a successful message.



4. Once complete, power off and unplug from the power cable. Switch the upgrade switch to **NORMAL**. Power the unit back on.
5. To check the firmware version, long press the **SELECT** button to enter the menu. Turn the knob until the display says **<System Version>** and press in the **SELECT** button to view the installed firmware version.

This firmware improves performance, bug fixes, and adds the ability to view song titles before selecting for playback.